



VOC free, no-clean, halide free soldering flux for spray applications

Description:

The Interflux[®] **PacFic 2009M** is an environmental friendly flux especially developed without the use of any volatile organic compounds.

The flux does not contain any halides, neither rosins nor resins. The absence of rosin and resin will give very low ICT contact problems.

PacFic 2009M has very good wetting capacity and excellent soldering on all popular board finishes. It is suitable for soldering with normal SnPb and lead-free alloys and for components and PCB-finishes with critical solderability.

The flux can be used for both wave and selective soldering and dip tinning.

PacFic 2009M allows a change-over from alcohol based fluxes to water based fluxes with virtually no disadvantages.



Products pictured may differ from the product delivered



Physical and chemical properties	
Density at 20°C	1,00 g/ml ± 0,01
Colour	clear
Odour	sweet
Solid content	3,7 % ± 0,15
Halide content	none
Flash point (T.C.C)	n.a.
Total Acid Number	25 mg KOH/g ± 2
IPC/ EN	OR/ L0

Key properties

- Absolutely halide free
- 100% water based
- Resists high temperatures
- Practically odourless
- Improved through hole filling
- High compatibility with conformal coatings

Why VOC-free?

- No risk of fire caused by flux ignition
- No Volatile Organic Compounds (VOC) emission caused by flux evaporation
- No alcohol smell in the production area caused by flux evaporation
- No use of flux thinner
- No need for monitoring of flux solid content
- Lower flux transport, storage and insurance costs
- A general reduction of flux consumption up to 30%



Applying the flux


The PacIFic 2009M is designed to be applied by means of a spray fluxing unit. It is advised to use a double spray stroke during fluxing, whenever possible and to keep the flux air pressure low enough to avoid flux being forced in between the PCB and soldering carrier. The nozzle traverse speed should be set to a value which ensures that every point on the board(s) is being sprayed twice, once from each side. This results in a 50% overlap on the spray pattern. This will give the most uniform spray pattern coverage. Spray pattern coverage can be checked by passing a piece of cardboard through the spray fluxer and removing it before it reaches the preheating. Check spray volume by passing a glass plate or empty circuit board through the fluxer and remove it from the machine before it reaches the preheating. There may be no drops present. Drops are a sign of excessive flux and are difficult to evaporate. To start, it is advisable to reduce the flux amount with about 30% compared to most alcohol based fluxes. Reduce the flux amount until defects typical for a too low flux amount like, webbing, flagging, shorts and icicles are observed. From this point increase the flux level again until defects disappear.

Preheating

The recommended preheat temperature measured on the topside of the boards is 80°C-160°C. This value is retrieved from practical experience. All water should be evaporated from the boards before hitting the wave. Hot air convection preheating facilitates water evaporation but it is advisable to avoid hot air temperatures above 150°C when possible.

Preheat slope: 1-3°C/s

Always take into account the physical properties of the board, components and soldering application in order to get an optimal final result .



Example of a measured temperature profile

Wave contact

Typical wave contact or dwell time value is 3-4s when using a single solder wave. For double wave soldering systems typical values are 1-2s for the first wave and 2-4s for the second wave. Lower total dwell time limit is 2s. Solder wetting can be optimal at lower contact times however longer contact times facilitate total flux wash off from the boards. The maximum upper limit will be determined by flux exhaustion and physical limitations of the board and components. Indications for flux exhaustion are bridging, icicling, webbing,...



Test results

conform EN 61190-1-1(2002) and IPC J-STD-004A

Property	Result	Method
Chemical		
Flux designator	OR LO	J-STD-004A
Qualitative copper mirror	pass	J-STD-004A IPC-TM-650 2.3.32
Qualitative halide		
Silver chromate (Cl, Br)	pass	J-STD-004A IPC-TM-650 2.3.33
Quantitative halide	0,00%	J-STD-004A IPC-TM-650 2.3.35
Environmental		
SIR test	pass	J-STD-004A IPC-TM-650 2.6.3.3
Qualitative corrosion, flux	pass	J-STD-004A IPC-TM-650 2.6.15
Corrosion test	pass	Test Bono

Safety

Please always consult the safety datasheet.



Packaging

PacFic 2009M is available in the following packages:

1L HDPE bottle

10L and 25L HDPE drums

200L HDPE barrel

Other packaging available upon request.

Trade name : PacFic 2009M VOC-Free No-Clean Soldering Flux

Disclaimer

Because Interflux[®] Electronics N.V. cannot anticipate or control the many different conditions under which this information and our products may be used, we do not guarantee the applicability or the accuracy of this information or the suitability of our products in any given situation. Users of our products should make their own test to determine the suitability of each such product for their particular purposes. The product discussed is sold without such warranty, either express or implied.

Copyright:

INTERFLUX[®] ELECTRONICS N.V.

**Latest version of this
document on:**

www.interflux.com

